



Recommended Finishing Procedure for your Carbon Fiber Parts from
Aerosport Products

1. Start out by cleaning all of the carbon surfaces with a wax and grease remover. You want to make sure that any leftover mold release has been removed before moving forward.
2. You will then use a 320-grit sandpaper to scuff/sand all surfaces that you plan on clearing. Make sure that there are no shiny surfaces before the first coat.
3. Again, clean all of the carbon surfaces with a wax and grease remover. This will help clean everything and remove any previously missed release.
4. Spray the panel with a light coat of clear. Look for any pinholes and try to fill them with clear. You can do this by either spraying a little heavier in trouble areas or by hand filling larger holes with a dropper.
5. Sand the entire panel again with 320-grit sandpaper.
6. Re-spray the entire panel. You may still have a few pin holes. If so, a third coat will be needed.
7. Inspect the finish after this coat of primer. Based on your individual preference you may repeat Steps 4-7 until you are satisfied.

If you have any questions, feel free to contact us.

Aerosport Products

Info@AerosportProducts.com

614-834-8659