

Headset cord clips Install



Measure over $5/16''$ over from inside lip and center
In the front back then drill a $3/16''$ hole. Drill hole very slow



Snap clips in. Then spread clip at joint and lift the longer tap
install wires so they are not twisted. Then make sure the longer
tab is under the shorter